



ij normalny "A - A"

6+466,00 - 86+539,00




### ГЛАВНЫЙ "Б - В"

24 - 86+546,24




bi normalny "C - C"

86+627,92; 88+439,71 - 88+459,71




ekrój normalny "D - D"

86+668,46; 86+695,63; 86+763,58  
izdania


krój normalny "E - E"

km: 86+643,46 - 86+758,00




zekroj normalny "f - f"

00'171.10 = 00'000.10 .1111




ekrój normalny "G - G"

km: 88+200,00 - 88+300,00




roj normalny "G' - G"

0 - 89+430,00 (wymiana podbudowy na szerokość




### Przekroj normalny H-H



**jezt/n/a**



zwiększ normalny przepływ pod zjazdem



- [illegible]

[illegible]